LED Wall Sconce



START FROM HERE

- Make sure **POWER** is **COMPLETELY OFF** at the fuse box
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area
- Wear gloves at all time during this installation
- Read instructions carefully before you start assembly

3. Attach mounting plate (1c) to electrical junction

box (1a) using junction box screws provided (1e) in

• Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

hardware package

Please Note:

- This Kuzco LED fixture comes with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- For dimming, an ELV (Electronic Low Voltage) or TRIAC type of dimmer is required
- 120V input
- Remove fixture from its original package
 Make proper electrical connections (black to hot "L", white to neutral "N", ground to "GND") with wire nuts (1b) provided in hardware package and place driver removing canopy screws (2b)
 Make proper electrical connections (black to hot "L", white to neutral "N", ground to "GND") with wire nuts (1b) provided in hardware package and place driver (4a) inside electrical junction box (1a)
 - **5.** Attach canopy **(2a)** to mounting plate **(1c)** with canopy screws **(2b)**



